

Optional AC / DC Converter Power Supply:
 Any 120VAC \Leftrightarrow 6 to 9 VDC Adapter.
 RadioShack (273 - 1454D) 6 v, 150 mA
 Diode on Battery Supply

Extra Components &
 off-board Wires in
 RED




Figure 10. Top of Reader PCB showing components and component orientation (off-board parts shown with dashed connectors)

Note: Battery clip, LED, rocker switch and host computer plug are off-board components connected with wire/cable (dashed lines).